PLEASE READ THE ENTIRE INSTRUCTION SHEET BEFORE STARTING INSTALLATION.


PLEASE REFER TO THE OPERATORS MANUAL FOR YOUR SPECIFIC COMBINE FOR PERTINENT SAFETY PRECAUTIONS THE TERMS. "LEFT", "RIGHT", "FRONT", & "REAR" ARE DETERMINED BY FACING IN THE DIRECTION THE COMBINE WILL TRAVEL WHEN IN USE.

IMPORTANT:


Before you begin installation, compare the contents with the enclosed "Packing Slip" to confirm that you have received the correct panels and associated hardware for your model header. Please refer to the operators manual for your specific combine for pertinent safety precautions.


Panel Layout:

20ft










Hydraulic Cylinder Safety Stop

Lower safety stop (A) onto hydraulic cylinder rod.

Setting Reel Safety Stops

Caution: Lower both safety stops (B) when working under or on the reel.

- · Sound horn, start combine engine and raise reel all the way. Stop combine engine, set parking brake and remove key.
- · Unhook stop (A) from storage clip, lower stop completely and ensure lock snaps are locked on cylinder rod. Repeat steps for other side of platform.



IMPORTANT: The floor strippers (5/8 x 1 steel angle) are required to secure the rear of the liner. If your header is not equipped with floor strippers, it will be necessary to acquire them from your dealer before you can successfully install the liner kit.






1. Raise each end of the auger approximately 3/4 inch to allow the floor strippers to be removed thru the front of the header.



2. Remove both floor strippers.

Note: With floor strippers removed, thoroughly clean the auger trough to remove all dirt and crop residue.





3. Insert the center panel (GPJP600C) under the auger. Center the panel in the rear opening.





4. Position the panel and the hold down strip labeled GPJHD5450 immediately behind the metal frame as illustrated.



5. Center the hold down strip between the cut outs as illustrated.



6. Drilling with the 13/64" drill bit supplied, secure the hold down strip with the 3/16 x 1/4 rivets. Install a rivet in each hole before drilling the next hole.

WARNING Proper application, installation, and operation of any machine and/or installation incorporating products sold by Lundell Plastics Corporation™ is the responsibility of the purchaser and/or end user. All local, state, and federal safety codes must be followed. Lundell Plastics Corporation™ is specifically not responsible for property damage and/or personal injury, direct or indirect, for damages and/or failures caused by improper design, application, installation, operation, abuse, and/or misuse of its' products. Conveyors must never be installed, readied for operation, or operated without proper covers and quards installed and securely in place.










- 7. With the leading edge of the panel secured, wedge the liner tight against the auger trough floor with the wooden shims supplied. Working from the center outward, install the left center panels and left end panel using the same procedure as described in Steps 5 and 6.
- 8. Position the panels with a 3/16 inch gap at each joint using the gauge block supplied.
- 9. Install the mating hold down strips with no gap at their joints. Secure the hold down strips as described in Steps 6.

When using power tools, basic safety precautions should always followed to reduce the risk of personal injury. WEAR SAFETY GLASSES OR GOGGLES.





10. Re-install the left floor stripper. With the center and all the left side panels secured on the leading edge and held down with the wooden shims, use the 11/32" drill bit supplied to drill the poly panels at each floor stripper mounting hole location from underneath the header as illustrated.





- 11. Remove the wooden shims and repeat the process on the right side.
- 12. Fasten the liner across the rear opening. Using the pre-drilled holes as a guide, drill thru with the 9/32" drill bit supplied. Secure the liner with the 1/4" drive rivets.
- 13. Re-adjust auger height.

WARNING Proper application, installation, and operation of any machine and/or installation incorporating products sold by Lundell Plastics Corporation™ is the responsibility of the purchaser and/or end user. All local, state, and federal safety codes must be followed. Lundell Plastics Corporation™ is specifically not responsible for property damage and/or personal injury, direct or indirect, for damages and/or failures caused by improper design, application, installation, operation, abuse, and/or misuse of its' products. Conveyors must never be installed, readied for operation, or operated without proper covers and guards installed and securely in place.