

Folding Auger Kit INSTALLATION INSTRUCTIONS

PLEASE READ THE ENTIRE INSTRUCTION SHEET BEFORE STARTING INSTALLATION. Please refer to the manufacturer's operator's manual for pertinent safety precautions. THINK SAFETY. WEAR SAFETY GLASSES.





Folding Auger Kit Installation Instructions

- 1. Slide the shorter poly auger section into the hopper tube of the auger. Install the bolt to attach the flighting to the motor. Do not over tighten the nut. Tighten it just snug to the plastic hub.
- 2. Take the bolt out of the bottom of the upper (longer) poly auger section.
- 3. Slide the longer poly auger section into the upper tube of the auger. Guide the 1" shaft through the bearing at the top end. Do not set the lock collar yet.
- 4. Slide the cable of the bottom section into the bottom end of the upper section. (This cable helps the section line up.)
- 5. Make sure the cable end is beyond the bolt hole of the upper section. Re-install the bolt in the bottom of the upper section.
- 6. Extend the auger, making sure the upper poly auger section slides down enough to join the lower poly auger section when the tube comes together. Make sure the sections are tight by pushing on the 1" shaft at top of the auger.
- 7. Set the locking collar at the top bearing.

WARNING Proper application, installation, and operation of any machine and/or installation incorporating products sold by Lundell Plastics Corporation[™] is the responsibility of the purchaser and/or end user. All local, state, and federal safety codes must be followed. Lundell Plastics Corporation[™] is specifically not responsible for property damage and/or personal injury, direct or indirect, for damages and/or failures caused by improper design, application, installation, operation, abuse, and/or misuse of its' products. Conveyors must never be installed, readied for operation, or operated without proper covers and guards installed and securely in place.

Visit us online at www.lundellplastics.com to see other innovative products!

© Lundell Plastics Corporation · 400 W Market St. · Odebolt, IA 51458 · P 712.668.2400 · TF 877.367.7659 · F 712.668.2402